

Here are three scenes:


- 1, out of home
- 2, at home
- 3, standard

If you want to switch off motion detection of all devices in the App, Please tap 'at home'.

If you want to switch on motion detection of all devices, please tap 'out of home'

Choose 'Standard', then you need to set the device one by one, like the following pictures.

Tap



Tap here to play live video

Tap here to set motion detection time/sensitivity/audio alert

Protection

- Motion Detection
- Sensitivity Middle >
- Audio alerts Mute >
- Warning time All day Allday >

When the Secure Protection is on, the motion detection will turn on automatically, and send alerts according the time interval setting.

